


Bristol Chaise Lounge
Chaise longue Bristol
Chaise Lounge Bristol

Assembly Instructions
instructions de montage
Instrucciones de montaje


BERLIN
GARDENS






Hardware Included
Matériel inclus
Herrajes incluidos


71516 x4




7114 x20





6114 x12




6214 x10




62516 x2




214412 x2




214312 x14




214300 x4



214234 x2




2516300 x2



(9532) x1

Items Not Included
Articles non inclus
Artículos no incluidos

7/16" + 1/2" Wrench
Clé 7/16" + 1/2"
Llave de 7/16" + 1/2"




1
A
B x2
C
D x2


6114 x10







71516 x4




2516300 x2



214312 x12




62516 x2




2
E




6214 x2




7114 x4



214312 x2




3^F





6214 x2




7114 x4



214300 x2




4^G
^H
I x2





6214 x2



7114 x2




214234 x2




5


6214 x4



7114 x10



214300 x2



214412 x2

