



Bristol Single Glider
Planeur simple Bristol
Planeador único Bristol


Assembly Instructions
instructions de montage
Instrucciones de montaje

BERLIN
GARDENS







A




B




C




D




E



F




G




H

I x4



81800 x4




Hardware Included


Matériel inclus

Herrajes incluidos


75516 x4




61516 x4



62516 x8




63516 x4





6114 x18





214200 x8





2516212 x8





214412 x2




214300 x4




214314 x2



214312 x2



(9532) x1



Items Not Included

Articles non inclus



Artículos no incluidos

7/16" + 1/2" Wrench



Clé 7/16" + 1/2"

Llave de 7/16" + 1/2"







3 E
F
G
H





6114 x8




214200 x8




4 I x4




6114 x4




214300 x4




5




63516 x4





62516 x4




75516 x4



2516212 x4





Slide assembled base underneath glider in the position shown and attach to brackets.

Faites glisser la base assemblée sous le planeur dans la position indiquée et fixez-la aux supports.

Deslice la base ensamblada debajo del deslizador en la posición que se muestra y fíjela a los soportes.

